Head

Top Rail

Top Sash

Meeting Rail

Bottom Sash

Bottom Rail

Sill

A

A = Window height for sash balance measurement